

# Update LKx Pro touch screen firmware

Wednesday, December 16, 2020 10:39 AM

## Document Information


Version	Date	Author	Remark
1.0	2020-12-16	longer3d-freejoe	first release

## Application model


LKx Pro series

## Start

1. Inserted micro SD card to card reader, then plug it into your PC.
2. Right click the your SD card disk volume icon, click "Format..." item in pop-up menu.




3. Select "FAT32" file system, and "4096 bytes" in format dialog, then click "start" button.



4. Find "DWIN\_SET" folder in "UI\_DW\_LKx\_PRO\_xxx" and copy "DWIN\_SET" folder to the root directory of SD card. (Note: the folder name "DWIN\_SET" should not be modified)



5. Remove SD card from PC, then insert it into the touch screen card slot.




6. Reboot your printer, then waiting for the screen firmware update. You will see the information when it done as shown below:

**SD Card Process... END !**  
**Download .CFG Files : 0001**

**Download Code Files : 0000**  
**Download .LIB Files : 0000**  
**Download .H2K Files : 0001**  
**Download .BIN Files : 0006**  
**Download .D2K Files : 0000**  
**Download .ICO Files : 0005**  
**Download .WAV Files : 0000**  
**Download .BMP Files : 0147**  
**Output .DAT Files : 0000**

7. Remove card from screen. reboot your printer. check the firmware version in "ABOUT" menu.
8. Reformat your SD card file system back to "32 kilobytes" allocation unit size to prevent from some potential problem.



9. Have fun! : )