



1. Let the computer recognize the sd card



2.Format the sd card and select FA T32 and 4096 bytes.



3. Select this folder DWIN_SET and copy it to the sd card.
(Note: the folder name must be the same)



4. Insert the sd card into the screen



5. Wait for the screen firmware update to complete

